




**Adjusting your LG
TV audio settings**

**This is likely due to a recent LG
software update causing your TV
to default to factory settings**



**As our meter relies on the correct
audio settings, please follow the
steps below to readjust them:**



Using your TV remote, press the settings or cog button

