



## Restarting the People Meter 7

**One of the TV Meters in your home  
has locked up and become  
unresponsive**


**This may have been caused by a  
software update or change to a meter  
parameter while your TV was in  
stand-by**

**Lets get that meter back up and  
running, using these quick and simple  
steps!**

**Step 1: Locate the power button on the side nearest to the power lead**




**Step 2: Hold down the power button for 10 seconds**



**If successful, you should see the  
following screens**



**The Kantar loading screen can take  
between 1 and 3 minutes to complete**



**Once complete, the Meter will return  
to the snooze screen**



**Your People Meter should now be  
fully operational**



**You can test this by turning your TV  
on and logging in**

